

# CD-Series Replacement Elements

PART NUMBER	MODEL	LENGTH	WATTS	VOLTS	FITS
10-1055	E-1424	30"	1500	240	CD-3024
10-1058	E-1427	30"	1500	277	CD-3027
10-1060	E-1428	30"	1500	208	CD-3028
10-1062	E-1448	30"	1500	480	CD-3048
10-1085	E-2024	36"	2000	240	CD-4024
10-1090	E-2027	36"	2000	277	CD-4027
10-1095	E-2028	36"	2000	208	CD-4028
10-2000	E-2048	36"	2000	480	CD-4048
10-2010	E-2524	36"	2500	240	CD-5024
10-2015	E-2527	36"	2500	277	CD-5027
10-2020	E-2528	36"	2500	208	CD-5028
10-2025	E-2548	36"	2500	480	CD-5048
10-2030	E-3024	58"	3000	240	CD-6024
10-2035	E-3027	58"	3000	277	CD-6027
10-2040	E-3028	58"	3000	208	CD-6028
10-2045	E-3048	58"	3000	480	CD-6048

*For our helpful instruction video, "How to Replace an Infratech Heating Element - W/W/D-Series," please visit [www.infratech-usa.com](http://www.infratech-usa.com) or contact customer service.*